



BVS ELITE 5 DUST COLLECTOR

The Super Machine : Advantages

- Maximum CFM versus power
- Very light and sturdy
- Modular
- Removable plenums: One for Commercial projects designed for maximum efficiency and capacity, the other for residential projects
- Pressure gage: this will tell you when to change your filters
- 8 caster wheels

Unique variable speed technology: Tested and sold since the last 5 years

- Démarrage lent afin de minimiser la surtension
- 0 PCM à 5000 PCM ce qui permet d'ajuster la demande en énergie
- Surface de filtration adaptée à la capacité réelle des filtres. Maximize la la puissance des turbines et garantie efficacité des filtres.
- Plénums de filtrations
- Aspiration maximum de poussière

Just plug and play

120 - 115 - 220 50 hz 60 hz

Air Flow: 5,000 CFM 4,000 CFM D.O.P tested

Variable speed motor: 0 to 5000 PCM

Electric motor: two 1 1/2 hp

Vacuum: up to 6.4" STATIC PRESSURE

Filtration (pre): pre-filtration pad (optional)

Filtration 1 : Electrostatic or pad filtration

Filtration 2 : 65% efficient bag

Filtration 3 : 2 x 99.97% HEPA 2,000 CFM rated or 95% 2,000 CFM rated

Power: 2x 120V or 220V 60 or 50 hz

Fan: two back incline

Extension : Deux extensions de 25" 12 gage

Power cord: two 50" 12 gage

Hose: 25 x12" hose superflex flex duct

Finish color: yellow

Total dimensions: 32" W x 34" H x 44" L with outside filters

MODULES (see diagrams)

Module 1: 2 x fan turbines

Module 2: filter section

Module 3: residential A or commercial B plenum

Input: 12" diameter